


# Cable Connections


- Same coupler



(AN650)




# Coupler Position




(GSX-R600/750/1000)



(GSF650/1250)




(GSR600)



(DL1000)


# Coupler Position



(VZR1800)



(VZ800)




(AN250/400K3-K6)




(AN250/400K7-)

# Coupler Position




(RV125)



(UH125/200)




(LT-A450X/LT-A700X)



(LT-R450)

# Couplers for ABS model



(6 terminals)

Mode Select Switch for  
Engine and SDS



(4 terminals)

Mode Select Switch for  
ABS

Mode  
Select  
Switch

ECM

**SDS**

Mode  
Select  
Switch

ABS control unit