



[M109Riders.com](#) > [Message Boards](#) > [How to, step by step](#)

[How to disable the Fi light..\(after removing Set Valve\)](#)
(RECREATED)

Welcome, **BigpapaM109**.

You last visited: 10-23-2008 at 02:13 AM

[Private Messages](#): Unread 0, Total 902.

Your PM box is 90% full.

[User CP](#) [Home](#) [Forums](#) [FlashChat](#) [FAQ](#) [Members List](#) [Calendar](#) [New Posts](#) [Search](#) [Quick Links](#) [Log Out](#)

How to, step by step This board will be used only for step by step instructions on maintenance and installation procedures related to the M109R and valuable links.



[Thread Tools](#) [Search this Thread](#) [Rate Thread](#) [Display Modes](#)

05-20-2008, 04:23 PM

#1

[BigpapaM109](#)

Very Active Member



Join Date: Jul 2007

Location:

Germantown, MD

Posts: 2,300




[How to disable the Fi light..\(after removing Set Valve\)](#) (RECREATED)

Wildracing22 lost his pictures and was kind enough to mail them to me. I had to recreate this thread and the text on the pictures. I used this a while ago and it worked flawlessly but all I did here was try and recreate so if anything is missing or not clear, I apologize. I also made a pdf that you can get [here](#) so we don't lose this valuable info.



Undo this allen bolt.





Using a small screwdriver, push in the center of this pin and remove it. Gently push the body panel forward to release the front from the front slide clip, now pull out on the body panel. There are two anchors mounted in rubber toward the rear of this panel, they will pop out by simply applying outward pressure. At this point swing the body panel around the rear footpeg and allow to hang from the seat release cable.





After releasing these bolts the computer and it's mounting cage will be free.







Push the pic into the pin hole as far as you can and the lock will release. Be very careful as if you start destroying the plastic it may make it hard to plug the harness back in. If that happens your best course of action is to just cut the wire.



Here it is removed.

Reverse what you did and put it back together.



Too much crap to list



05-20-2008, 11:09 PM

#2

Anders

Very Active Member



Join Date: Jun 2006
Location: Denmark
Posts: 211

Re: How To Disable the S.E.T. Valve (RECREATED)

AND - it is certified by Suzuki.

This is the instruction from Suzuki in a ServiceBulletin:


The text says: "Cut pin 62, if SET valve and O2 sensor is removed. Picture shows connector on ECM."

My own experience is, that you do not need to remove all the stuff. I just removed the side cover, used a screwdriver to pry out the connector, twisted it out in the open so I could remove the pin. Lot easier.

<http://www.winthers.org/service/VZR1800K620SET2002.pdf>



For full view of the bike, goto http://www.winthers.org/service/1800_m/index.htm



05-21-2008, 06:01 AM

#3

rynosback

Very Active Member















Re: How To Disable the S.E.T. Valve (RECREATED)

Great find and repost Papa.



Bang for the Buck Mods

<http://www.m109riders.com/forums/showthread.php?t=95024>

<p>Join Date: Apr 2006 Location: Annapolis, Md Posts: 8,440</p> 	<p> Quote </p>
<p> 05-21-2008, 09:02 PM</p> <p>Decibles Very Active Member</p> <p>Join Date: May 2006 Posts: 545</p> 	<p>#4</p> <p> Re: How To Disable the S.E.T. Valve (RECREATED)</p> <p>Thanks for taking the time to straighten out this how-to.</p> <p>I'm suprised though that the service manual says to do this when removing the SET...I thought other sensors were tied in with this pin. 🙄</p> <p> Quote </p>
<p> 05-23-2008, 03:37 PM</p> <p>ssandyman Active Member</p> <p>Join Date: Apr 2008 Posts: 54</p> 	<p>#5</p> <p> Re: How To Disable the S.E.T. Valve (RECREATED)</p> <p>Worked just as described.. 🙄 I have a question. If I remove the S.E.T. valve completly will the JSD-3 still be functional or just a waste of time to still have plugged in 🙄</p> <p> Quote </p>
<p> 05-24-2008, 04:06 AM</p> <p>BigpapaM109 Very Active Member</p>  <p>Join Date: Jul 2007 Location: Germantown, MD Posts: 2,300</p> 	<p>#6</p> <p> Re: How To Disable the S.E.T. Valve (RECREATED)</p> <p>Quote:</p> <div><p>Originally Posted by ssandyman <i>Worked just as described.. 🙄 I have a question. If I remove the S.E.T. valve completly will the JSD-3 still be functional or just a waste of time to still have plugged in 🙄</i></p></div> <p>Still fully functional.</p>  <p>Too much crap to list</p> <p> Edit  Quote </p>
<p> 05-24-2008, 05:10 AM</p> <p>ssandyman Active Member</p> <p>Join Date: Apr 2008 Posts: 54</p> 	<p>#7</p> <p> Re: How To Disable the S.E.T. Valve (RECREATED)</p> <p>👍👍 Thanks</p> <p> Quote </p>
<p> 05-26-2008, 04:29 AM</p> <p>Wildracing22 Very Active Member</p>	<p>#8</p> <p> Re: How To Disable the S.E.T. Valve (RECREATED)</p> <p>Great Job BigPapa, I have been so busy lately and I know that alot of people have</p>

Join Date: Apr 2006
Posts: 194



used this before. Thanks again 🍷 🍷



05-26-2008, 05:57 AM

#9

[BigpapaM109](#)

Very Active Member



Join Date: Jul 2007
Location: Germantown, MD
Posts: 2,300



Re: How To Disable the S.E.T. Valve (RECREATED)

Quote:

Originally Posted by **Wildracing22**

Great Job BigPapa, I have been so busy lately and I know that alot of people have used this before. Thanks again 🍷 🍷

Actually the thanks goes out to you. It was a great how-to and helped me do mine so it is the least that I could do. Thanks for emailing me the pics 🍷



Too much crap to list



05-28-2008, 03:14 AM

#10

[Zuki300](#)


Very Active Member

Join Date: Mar 2008
Location: Roseville, CA
Posts: 112



Re: How To Disable the S.E.T. Valve (RECREATED)

Thanks for reposting this! Another tip I got from James was to forget about trying to use something small to pry the pin out. I just grabbed the wire from the backside with some needle nose and gently pulled and it let go and pulled right out. Bent it over and shrink wrapped it and it's good to go.



06-05-2008, 04:14 PM

#11

[thorleifur](#)

Member

Join Date: May 2008
Posts: 2



Re: How To Disable the S.E.T. Valve (RECREATED)

I have a questjon ,is this too turn off the FL light ? I just got M109R from USA with cobra pipes and the FL light is flassing.
Thanks from Iceland



06-05-2008, 04:37 PM

#12

[Nashty](#)

Very Active Member

Re: How To Disable the S.E.T. Valve (RECREATED)

Quote:



Join Date: Feb 2008
Location: Lake Ridge, VA.
Posts: 151

Originally Posted by **BigPapaM109**

Actually the thanks goes out to you. It was a great how-to and helped me do mine so it is the least that I could do. Thanks for emailing me the pics



What is the purpose of disabling the S.E.T. Valve 🙄🙄

06 Black 9\De-Badged\De-Beavered\Kuryakyn ISO Grips\GI-Pro\Stebel Air-horn\Shift Kit-EVO-S93\Motolights\Kriss Industries Headlight Modulator\Kriss Industries BLT (Break Light\Turn-Signal Flasher)\Kuryakyn Dual ISO Pegs\KewlMetal 2" Chrome Hole Risers\Cycle House Levers and Kickstand\Suzuki Engine Guards\2.5" lowering bones\SS-Brake-Throttle Cables\K&N Filters\PCIII\Cobra Swept Exhaust\Thunder Monster Baffles\Stock Chrome Wheels\Front Gaffler Rotors.



06-05-2008, 04:52 PM

#13

[gtorockz](#)

Active Member

Join Date: Apr 2008
Posts: 75

Re: How To Disable the S.E.T. Valve (RECREATED)

Quote:

Originally Posted by **Nashty**

What is the purpose of disabling the S.E.T. Valve 🙄🙄

and does this mean if the SET valve just quits working the bike will still run fine?

North Carolina



06-06-2008, 12:50 AM

#14

[BigpapaM109](#)

Very Active Member



Join Date: Jul 2007
Location: Germantown, MD
Posts: 2,300



Re: How To Disable the S.E.T. Valve (RECREATED)

I don't wanna babble on something I am not positive so you will probably need to search. However, I believe if you don't disable the set valve then the bike goes into limp mode when the FI light comes on.



Too much crap to list



06-06-2008, 05:04 AM

#15

[Wildracing22](#)


Very Active Member

Join Date: Apr 2006
Posts: 194

Re: How To Disable the S.E.T. Valve (RECREATED)

Bigpappa, Maybe you should change the subject field to How to disable the Fi light..(after removing Set Valve). (How to disable the SET valve) is a little misunderstanding for the newer members on what the purpose of the how to is. Just my .02

By the way great job on fixing the how to.. 🙄🙄



06-06-2008, 05:16 AM

#16

[BigpapaM109](#)

Very Active Member

Re: How to disable the Fi light..(after removing Set Valve) (RECREATED)

Thank you sir....great idea. I changed the name as it really does make sense.



Join Date: Jul 2007
Location: Germantown, MD
Posts: 2,300



Too much crap to list



06-08-2008, 07:20 PM

#17

Fletch109

Active Member

Join Date: Mar 2008
Location: Fayetteville, Ar
Posts: 39



Re: How to disable the Fi light..(after removing Set Valve) (RECREATED)

Wow thats was easy 15 minute job getting tools and everything.

I hope it rides the same now, I'll take it for a test spin later today but the light went off.



06-09-2008, 04:12 PM

#18

Fletch109


Active Member

Join Date: Mar 2008
Location: Fayetteville, Ar
Posts: 39



Re: How to disable the Fi light..(after removing Set Valve) (RECREATED)

Rode about a 100 miles yesterday on it and everything seems fine so I am happy thanks for posting this info.



Tags

Edit Tags

None

[« Previous Thread](#) | [Next Thread »](#)

Posting Rules

You **may** post new threads
You **may** post replies
You **may** post attachments
You **may** edit your posts

BB code is **On**
Smilies are **On**
[IMG] code is **On**
HTML code is **Off**

Forum Jump

How to, step by step

Go

All times are GMT -4. The time now is 03:03 PM.

[Contact Us](#) - [M109Riders.com](#) - [Archive](#) - [Top](#)

Powered by vBulletin® Version 3.7.2
Copyright ©2000 - 2008, Jelsoft Enterprises Ltd.